

Phantasm

Dynamic Phaser

Quick Start Settings

Note - If the ACD and/or ACS controls are shown, it is assumed the ACD and/or ACS switches are ON



Depth



Rate



Feedback



Width



Axis

Classic Vibrato



Depth



Rate



Feedback



Width



Axis

Sweet & Slow



Depth



Rate



Feedback



Width



Axis

Negative-Feedback Tremolo



Depth



Rate



Feedback



Width



Axis

Low & Slow



Depth



Sensitivity



Rate



Feedback



Width



Sensitivity



Axis

Toad Funk



Depth



Sensitivity



Rate



Feedback



Width



Sensitivity



Axis

Doug Funk